



Assembly instruction


Multilux F7M



















one person

Components of the chair:




1. *Backrest*
2. *Right armrest*
3. *Left armrest*
4. *Seat*
5. *Button to launching the backrest function*
6. *Lever for launching the function*
7. *Footrest*
8. *Central part*
9. *Base*







1



2 Lever in forward position. "Rocking function"
⚠ The footrest does not open

